


1. Brief

This document is the user manual for telink zigbee gateway controller software, and note that only the generic step is shown here, please refer to “AN_17110600-E2_Telink Zigbee 3.0 SDK Guide” for more information.


2. System Architecture



3. Step-by-Step Guide


Step 1: Open the port

- 1) Select the port number, and other options can use the default value.
- 2) Click on the “Open” button and open the port.



Step 2: Set the channel

- 1) Switch to the BDB page
- 2) Select a channel you want to use and click the “Set Channel” button.




Step 3: Start the network

- 1) Click the "Start Network" button to start the network

Step 4: Set the permit join interval

- 1) Switch to the MGMT page
- 2) Enter the address and interval
- 3) Click the "Permit Join" button



Step 5: Power on the Zigbee device to join the network before the interval is expired, and now you can use other commands to control the device.